

HILO OWNER'S MANUAL

WWW . XFUSIONSHOX . COM



30	TNC	ENTS	
		_	
	English		

อักษรไทย

nglish	
spañol	
rançais	
taliano	
eutsch	
養體中文	
6体中文	
ndonesia	30



CAREFULLY ASSEMBLE THE REMOTE LEVER AND SEAT POST HEAD.









MAKE BURE ALL 3 X'S ARE ON THE REAR SIDE OF THE HEAD UNIT.



04

HILD MAINTENANCE CYCLE

HILD MAINTENANCE CYCLE

ACTING ON ITS BEHALF.

ш	TICO MAINTENANCE O TOLE
	CLEAN DEBRIS FROM SEATPOST
	UBRICATE SEAL HEAD
	LEAN AND LUBRICATE CABLE UNDER SADDLE
	REPLACE CABLE AND HOUSING
	ULL SERVICE (REPLACE OIL/SEALS)
Γ	REPLACE BRASS KEY WAYS
\ \	ARRANTY
XANDTNUPE	ARRANTY USION PROVIDES A 24-MONTH WARRANTY ON SUSPENSION PRODUCTS TO COVER DEFECTS IN FERIALS AND/OR WORKMANSHIP. THIS WARRANTY LY APPLIES TO THE ORIGINAL OWNER AND IS NOT NASFERABLE. TO MAKE A WARRANTY CLAIM, YOU ST PROVIDE PROOF OF PURCHASE WITHIN THE MONTH WARRANTY PERIOD. THE WARRANTY RIOD BEGINS THE DATE OF PURCHASE AND WILL PIRE EXACTLY 24 MONTHS LATER. E ACCEPTANCE OF A WARRANTY CLAIM DURING

EVERY MONTH EVERY MONTH EVERY 3 MONTH 6 MONTH/50 HOURS AS NEEDED (DETERMINED BY SIDE PLAY) X-FUSION OR ITS AGENTS WILL DETERMINE IF THE FAILURE IS DUE TO WORKMANSHIP, DEFECTS IN MATERIALS OR PRODUCT ABUSE. THE WARRANTY GUARANTEE WILL BE VOID IF THE BUYER DOES NOT INFORM THE SELLER OF THE DAMAGE AFTER ITS DISCOVERY WITHIN 60 DAYS, X-FUSION AND ITS

WARRANTY OR NON-WARRANTY CLAIMS. TO MAINTAIN

VALID THE GENERAL GUARANTEE CONDITIONS FOR

ALL X-FUSION SHOCKS IT IS ABSOLUTELY NECESSARY

THAT THE BUYER EXECUTES THE PERIODICAL MAINTE-

NANCE AND THAT CLEANING AND MAINTENANCE ARE

CARRIED OUT ACCORDING TO THE MAINTENANCE

CHART WITHIN THE OWNERS MANUAL.

DRY CONDITIONS

06

EVERY RIDE

EVERY MONTH

EVERY MONTH 6 MONTH/50 HOURS AS NEEDED (DETERMINED BY SIDE PLAY)

WET CONDITIONS

EVERY RIDE

EVERY MONTH

LIMITATIONS OF WARRANTY

GENERAL EXCLUSIONS FROM THIS WARRANTY SHALL INCLUDE BUT ARE NOT LIMITED TO ANY

FAILURES CAUSED BY:
-INSTALLATION OF PARTS OR ACCESSORIES THAT

ARE NOT QUALITATIVELY EQUIVALENT TO GENUINE
X-FUSION PARTS.

-ABNORMAL STRAIN, NEGLECT, ABUSE AND/OR MISUSE.

-ACCIDENT OR COLLISION DAMAGE.

-MODIFICATION OR ORIGINAL PARTS.

-LACK OF PROPER MAINTENANCE (SEE MAINTENANCE SCHEDULE)

-ANY ATTEMPT TO DISASSEMBLE DAMPER ASSEMBLY.

-SHIPPING DAMAGES OR LOSS (PURCHASE OF FULL VALUE INSURANCE IS RECOMMENDED)

-DAMAGE TO INTERIOR OR EXTERIOR CAUSED BY IMPROPER CABLE ROUTING, ROCKS, CRASHES OR IMPROPER INSTALLATION.

-OIL CHANGES OR SERVICE NOT PERFORMED BY X-FUSION AUTHORIZED SERVICE CENTERS.

-CHANGING AIR PRESSURE IN SEAT POSTS WITHOUT

LIMITATIONS OF WARRANTY

AND/OR ROUTINE MAINTENANCE.

SPECIFIC EXCLUSIONS FROM THIS WARRANTY INCLUDE:

-PARTS REPLACED DUE TO NORMAL WEAR AND TEAR AND/OR ROUTINE MAINTENANCE. -PARTS SUBJECT TO NORMAL WEAR AND TEAR

X-FUSION MAKES NO OTHER WARRANTY OF ANY KIND, EXPRESSED OR IMPLIED. ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE THAT EXCEED THE OBLIGATIONS AND TIME LIMITS STATED IN THIS WARRANTY, ARE HEREBY DISOLAIMED BY X-FUSION AND EXCLUDED FROM THIS WARRANTY.

WARNING

- BEFORE EVERY RIDE, MAKE SURE YOUR SEAT POST CLAMP IS SECURELY TIGHTENED.
- ALWAYS RUN YOUR SEAT POST WITH AT LEAST THE MINIMUM INSERTION. FAILING TO DO SO COULD RESULT IN DAMAGE TO THE PRODUCT, YOUR BICYCLE AND SERIOUS PERSONAL INJURIES.
- COMPRESS POST COMPLETELY BEFORE EACH RIDE TO ENSURE THERE IS NO CABLE INTERFERENCE.
- REFER TO HANDLEBAR MANUFACTURER'S INSTRUCTIONS PRIOR TO INSTALLING REMOTE LEVER ASSEMBLY.
- SYSTEM UNDER PRESSURE.
 CONSULT TECHNICAL MANUAL
 ONLINE AT WWW.XFUSIONSHOX.COM
 BEFORE PERFORMING ANY SERVICE.